























# Essential equipment for professional electricians: Measure current and voltage with a single instrument




















Specifications

Basic accuracy figures for measurement ranges are indicated in parentheses.

Accuracy guaranteed for 1 year, Post-adjustment accuracy guaranteed for 1 year, Product warranty period is 3 years.

| AC measurement method              | MEAN value                                                                                                    |  |
|------------------------------------|---------------------------------------------------------------------------------------------------------------|--|
| Core jaw diameter                  | ф33 mm (1.30"), jaw thickness: 9.5 mm (0.37")                                                                 |  |
| Max. rated voltage to earth        | Jaw : CAT IV 300 V, CAT III 600 V<br>Voltage measurement terminal : CAT III 300 V, CAT II 600 V               |  |
| AC Current                         | 42.00 A/ 420.0 A/ 1000 A (±1.5% rdg.±5 dgt.)                                                                  |  |
| Frequency characteristics          | 50 to 60 Hz                                                                                                   |  |
| AC Voltage                         | 4.200 V to 600 V, 4 ranges (±1.8% rdg.±7 dgt.)                                                                |  |
| Frequency characteristics          | 45 Hz to 500 Hz                                                                                               |  |
| DC Voltage                         | 420.0 mV to 600 V, 5 ranges (±1.0% rdg.±3 dgt.)                                                               |  |
| Resistance                         | 420.0 Ω to 42.00 MΩ, 6 ranges (±2.0% rdg.±4 dgt.)                                                             |  |
| Continuity Check                   | nuity Check 42.0.0 $\Omega$ (±2.0% rdg.±4 dgt.)<br>Threshold of buzzer sound 50 $\Omega$ ±40 $\Omega$ or less |  |
| Display refresh rate               | 400 ms                                                                                                        |  |
| Operating temperature and humidity | -25°C to 65°C (-13°F to 149°F),<br>80% RH or less (no condensation)                                           |  |

| and humidity        | 80% RH or less (no condensation)                                            |  |  |
|---------------------|-----------------------------------------------------------------------------|--|--|
| Drop-proof distance | 1 m onto concrete                                                           |  |  |
| Standards           | Safety : EN 61010, EMC : EN 61326                                           |  |  |
| Functions           | Data hold, Auto power-saving function                                       |  |  |
| Power supply        | Coin type lithium battery CR2032×1                                          |  |  |
| Continuous use      | 120 hours                                                                   |  |  |
| Dimensions and mass | nsions and mass 57W×175H×16D mm (2.24"W × 6.89"H × 0.63"D), 100 g (3.5 oz.) |  |  |
|                     |                                                                             |  |  |

#### **AC FLEXIBLE CURRENT SENSOR CT6280 specifications**

|              | diameter diameter: 5 mm (0.20"), (Cable cross-section diameter: 5 mm (0.20"), tip cap diameter: 7 mm (0.28")) |  |
|--------------|---------------------------------------------------------------------------------------------------------------|--|
| AC Current   | 420.0 A/ 4200 A (±3.0% rdg.±5 dgt.)                                                                           |  |
| Cable length | 800 mm (31.5")                                                                                                |  |

## Lineup

| Model                 | AC CLAMP METER<br>3280-10F                                                                                  | AC CLAMP METER SET<br>3280-70F                                                                                                                    |
|-----------------------|-------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------|
| AC measurement method | MEAN value                                                                                                  | MEAN value                                                                                                                                        |
| Order code            | 3280-10F                                                                                                    | 3280-70F                                                                                                                                          |
| Includes              | 3280-10F<br>CARRYING CASE 9398<br>TEST LEAD L9208<br>Coin type lithium battery CR2032<br>Instruction Manual | 3280-10F<br>AC FLEXIBLE CURRENT SENSOR CT6280<br>CARRYING CASE C0205<br>TEST LEAD L9208<br>Coin type lithium battery CR2032<br>Instruction Manual |
| Image                 |                                                                                                             |                                                                                                                                                   |

# Options

**TEST LEAD L9208** 

**CARRYING CASE 9398** 

AC FLEXIBLE CURRENT SENSOR CT6280

(optional, includes C0205 and attachment)

**CARRYING CASE C0205** (optional, for storing the CT6280, L9208 and main body)

**TEST LEADS HOLDER 9209** 

Freely bendable

(optional, one end of each test lead is fixed to rear of case.)

CONTACT PIN SET L4933\* (optional)

SMALL ALLIGATOR CLIP SET L4934\* (optional)

\*Probe tips can be used on TEST LEAD L9208.









### **About AC measurement**

There are two methods for converting current into RMS values: the mean MS value indication) and the true RMS method (true RMS value indication).

The input waveform is treated as an undistorted sine wave (single frequency only). The AC signal mean is calculated, converted to an RMS value, and

The measurement error increases when the waveform is distorted.

Ideal for distorted current signals The legacy 3280-20F has been redesigned to deliver easier clamping

## **NEW AC CLAMP METER CM3289**

- Measure even harmonic waveform components using the True RMS method
- A new sensor profile yields outstanding ease of use
- Connect the CT6280 flexible sensor to measure up to 4199 A in thick or paired wires



Note: Company names and product names appearing in this brochure are trademarks or registered trademarks of various companies.

HIOKI E.E. CORPORATION

### **HEADQUARTERS**

81 Koizumi. Ueda, Nagano 386-1192 Japan https://www.hioki.com/



Scan for all regional contact information